

Fully Integrated Technology System Mustang

The FIT system is a modular approach to achieving the ultimate in chassis stiffness and strength through design. Although Stifflers brand products are engineered to function as a superior standalone component; the FIT system has taken the next step by developing these components to work as an *integrated system*. Countless hours of research and testing have gone into fully optimizing these systems, they are not just randomly conceived and grouped together parts. The basic FIT system is composed of Subframe Connectors, Stiffening Rails and Web Brace. Additional options to fully extract your car's potential include a Lower Chassis Brace and Spider Brace.

Kit Includes:

- 1 Set Subframe Connectors
- 1 Set Stiffening Rails
- 1 Set Web

Installation:

- 1. Open each product contained in the FIT System and remove each installation sheet. Thoroughly read all instructions before beginning the installation process.
- 2. For best results, it is recommended the components of the FIT System be installed in the following order:

Subframe Connectors -----> Stiffening Rails -----> Web Brace



